




Lenovo U41-70 Teardown, Tightening Hinges

Hinges on my U41-70 were a bit loose, decided to look inside.

Written By: fixer




INTRODUCTION

Hinges on my U41-70 were a bit loose, decided to look inside.

TOOLS:

- [Small Needle Nose Pliers](#) (1)
 - [Plastic Cards](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Tools+ Removing Backpanel Screws





- Remove 10 Phillips Screws

Step 2 — Removing Backpanel





- Use Plastic Card to loosen Plastic clips
- Carefully work your way around
 - The whole Backpanel is held in place by plastic clips around the left, right and front

Step 3 — Open!




- Remove Backpanel beginning at the front and working your way to the back

Step 4 — Tighten Hinges



- Locate Hinges at the back

Step 5 — Tighten Hinges 2, Done!



- Use Pliers or Spanner to tighten
 - Righty- Tighty
 - Lefty- Loosy
- Be careful not to tighten the bolts too strongly - you might later break the Plastic when trying to open the lid.

This document was last generated on 2017-06-21 09:09:53 PM.